

**Special tools required:**

- 65 5 400

*Replacement:*

Load operating software and carry out coding (refer to Diagnosis and Information System).



Open flap (1) in side panel, rear left.

Release navigation computer (2) with special tool 65 5 400 (3) and pull out.



Disconnect plug connections and remove navigation computer.